



Quick tents

25 m² Tent



The 25 m² quick assembly tent is designed for a versatile use as field hospital, command post, etc... both in urban and rural environments. It is composed by a waterproof PVC canvas with a steel tube structure.

Emergency

TECHNICAL SPECIFICATIONS

4.13 m width by 6.05 m length of usable floor area. 2.0 m height on the sides and 2.93 m height in the centre.

2.00m wide by 1.80m height door with Velcro® closures on each end, and two windows enhanced with mosquito nets on each side.

Each side can be separately lifted to enable connections between tents, or to use the canvas as gable roof.

Materials:

Structure:

- Manufactured with ø40 mm steel tubes with anti-corrosion protection.
- Composed of nineteen 2 m-length tubes and six 2.13 m-length crossbeams with pre-assembled connectors. The crossbeams, which constitute the roof, are interchangeable. This makes the assembly and the disassembly easier.
- *Weight:* 80 Kg.

Canvas:

- Fireproof double-fold M2 polyester H.T. 1100 dtex in warp and weft, finished in bright colours. 620 g/m² surface density and 0.48mm thickness.
- *Weight:* 50.0 Kg.